

## SPRING FLOOR ASSEMBLY

- 1) Determine the positions of your springs. (See next page for recommended positions, for 5' x 5' or 4' x 8' panels). Mark these positions for drilling on the boards.  
**Remember: mark and drill only the boards on which springs are being attached.**
- 2) Using a drill bit (7mm - 8mm), drill holes through the board for these positions.
- 3) Place a T-nut in each of the drilled holes, and drive in with a hammer.



- 4) Flip the board over. Attach the cap—with the screw and washer—to the T-nut through the board. Repeat for all positions.




- 5) With a rubber mallet, tap the springs into the caps that are attached to the board. Tap a cap on the other end of the spring. Flip the board over. It is ready to be used.





### SPRING LOCATIONS FOR 5' x 5' PANELS



### SPRING LOCATIONS FOR 4' x 8' PANELS

