



42' x 42' Spring Floor


Bottom Layer (Springed Panels)

Quantities:

64 — 5' x 5' Springed Panels

16 — 5' x 2' Springed Panels

1 — 2' x 2' Springed Panel





Tumbl Trak


Train Smart

42' x 42' Spring Floor

Top Layer (Flat Panels)

Quantities:


- 49 — 5' x 5' Top Panels
- 14 — 5' x 4.5' Top Panels
- 14 — 5' x 2.5' Top Panels
- 1 — 4.5' x 4.5' Top Panel
- 2 — 4.5' x 2.5' Top Panels
- 1 — 2.5' x 2.5' Top Panel






Tumbl Trak


Train Smart



The bottom panels have velcro on top, springs on bottom. Start in one corner with three bottom (springed) 5' x 5' panels. (Do not start at each corner and work toward center.) Carefully align the edges to be squared up.




Apply the top layer as shown, starting first with the one 2½' x 2½' panel and then the two 5' x 2½' panels. This secures perfect alignment of the bottom. (To maintain alignment, be careful not to walk on the unsecured bottom panels.)



Continue to add panels (expanding out from the original corner) with great attention to abutting the panels and keeping them square. All of the edges should align.

(Adding the top layer as you work across will keep the panels from wandering.)



Refer to the layout when you get to the far edges. Depending on the quality of panels, warping may occur. Generally the velcro will hold the boards in place, especially when it is covered with a foam product. In worst cases, you might have to temporarily place a weight on the offending panel or put a screw in the panel until the warp disappears. You are now ready to roll out your Carpet Bonded Form or Flexi-Rolls. **We thank you for your purchase.**