


42' x 54' Spring Floor

Bottom Layer (Springed Panels)

Quantities:

- 80 — 5' x 5' Springed Panels
- 10 — 2' x 5' Springed Panels
- 8 — 4' x 5' Springed Panels
- 1 — 2' x 4' Springed Panel




42' x 54' Spring Floor

Top Layer (Flat Panels)

Quantities:


- 1 — 2.5' x 2.5' Panels
- 1 — 2.5' x 4.5' Panels
- 17 — 2.5' x 5' Panels
- 7 — 1.5' x 5' Panels
- 1 — 1.5' x 2.5' Panel
- 1 — 1.5' x 4.5' Panel
- 70 — 5' x 5' Panels
- 10 — 4.5' x 5' Panels






Tumbl Trak


Train Smart




Start in one corner with three bottom (springed) 5' x 5' panels. (Do not start at each corner and work toward the center.) *Bottom panels have velcro on top, springs on bottom.* Carefully align edges to be squared up.



Apply top layer as shown, starting with one 2½ x 2½ and two 2½ x 5 panels. This secures the perfect alignment of the bottom. *To maintain alignment, be careful not to walk on unsecured bottom panels.*



Continue to add panels (expanding from the original corner) with great attention to abutting the panels and keeping them square. All edges should align. Adding the top layer as you work across will keep the panels from wandering.



Refer to the layout when you get to the far outside edges, as there may be cut pieces (depending on the finished floor size). *Please note that some velcro pieces may not connect with corresponding velcro pieces.*

**You are now ready to roll out your Foam,
Carpet Bonded Foam, or Flexi-Rolls to top off your floor.**

Baltic Birch is especially resistant to warping, and the velcro normally holds the boards in place (especially when covered with a foam product). However, some warping may occur. If this is the case, you may need to temporarily place a weight on the warped panel, or place a 1 ½” course decking screw in the panel until the warp disappears.

We thank you for your purchase.